



# Gateway NV52 Optical Disc Drive Replacement

This guide will give instructions on how to remove the Optical Disc Drive.

Written By: Tim En



## INTRODUCTION

The Optical Disc Drive is not required to be taken out to have more access to the other components of the laptop.

---



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [Heavy-Duty Spudger](#) (1)
-

## Step 1 — Optical Disc Drive



- Remove the single 3/16" screw with the Phillips #0 Screwdriver that secures the Optical Drive.

## Step 2



- Slightly wiggle the Optical Drive from the laptop using the Heavy Duty Spudger.

## Step 3



- Using your hands, gently slide the Optical Drive out of the slot.
- Set the Optical Drive in a safe designated area.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 01:18:33 PM.